

IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

INSTALLATION ON 4" JUNCTION BOX INTEGRAL DRIVER (120-277V) DIMMING 0-10V - TRIAC / ELV

- A- MAKE ALL NECESSARY CONNECTIONS (**FOLLOWING WIRING DIAGRAM AND POLARITY MARKING**) USING TWIST CONNECTORS (**NOT INCLUDED**).
- B- FASTEN THE MOUNTING CROSSBAR TO THE CANOPY USING (2) PHILLIPS SCREWS (**INCLUDED**).
- C- TURN THE CANOPY COUNTER-CLOCKWISE TO REMOVE IT FROM THE FIXTURE.
- D- INSTALL THE CANOPY ON THE MOUNTING CROSSBAR USING (2) 8-32 SCREWS (**NOT INCLUDED**), TO ALIGN SQUARE MODEL, PLACE THE CANOPY AS INDICATED IN DETAIL D.
- E- INSERT THE RETAINING CABLE LOOP IN THE CLIP.
- F- INSERT WIRES IN THE CONNECTORS (**SEE WIRING DIAGRAM BELOW**) AND PUSH THE LEVERS DOWN. ALIGN FIXTURE SCREWS WITH THE KEYHOLE SLOTS AND TURN CLOCKWISE, AVOIDING PINCHING ANY CONDUCTOR.

