

IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

NEW CONSTRUCTION PLASTER FRAME INSTALLATION (NC)

- A- ENGAGE (2) HANGER BARS IN MOUNTING FRAME SLOTS AND CONNECT THEM TOGETHER.
B- FASTEN HANGER BARS TO CEILING STRUCTURE WITH APPROPRIATE SCREWS (NOT INCLUDED). MOUNTING FRAME MUST BE FLUSH WITH CEILING STRUCTURE.
C- INSTALL DRYWALL AND DO CUT-OUT OPENING (SEE DIMENSIONS BELOW).

A + B

Labels: CEILING STRUCTURE, SCREW (NOT INCLUDED), HANGER BARS, MOUNTING FRAME SLOT, (B), (A)

C

Label: CUT-OUT

TRIM		TRIMLESS	
ITEM	CUT-OUT DIMENSIONS (A x B)	ITEM	CUT-OUT DIMENSIONS (A x B)
BN-LOG4RT-NC	Ø4" (Ø100mm)	BN-LOG4RL-NC	Ø4 1/8" (Ø105mm)
BN-LOG4ST-NC	3 7/8" x 3 7/8" (97mm x 97mm)	BN-LOG4SL-NC	4" x 4" (100mm x 100mm)
BN-LOG5RT-NC	Ø5" (Ø125mm)	BN-LOG5RL-NC	Ø5 1/8" (Ø130mm)
BN-LOG5ST-NC	4 7/8" x 4 7/8" (122mm x 122mm)	BN-LOG5SL-NC	5" x 5" (125mm x 125mm)
BN-LOG6RT-NC	Ø6" (Ø150mm)	BN-LOG6RL-NC	Ø6 1/8" (Ø155mm)
BN-LOG6ST-NC	5 7/8" x 5 7/8" (148mm x 148mm)	BN-LOG6SL-NC	6" x 6" (150mm x 150mm)

FRAME KIT INSTALLATION FOR TRIMLESS MODELS

- A- PLACE FIXATION BRACKET TABS TO THE DESIRED POSITION DEPENDING ON CEILING THICKNESS. MAKE SURE THE RETAINING CABLE IS LOOSE IN THE CEILING.

A

	CEILING THICKNESS	
MODELS	POSITION 1	POSITION 2
LOG4	1/8" - 3/8" (3mm - 10mm)	3/8" - 7/8" (10mm - 22mm)
LOG5	1/8" - 3/4" (3mm - 19mm)	1/2" - 1 1/4" (13mm - 32mm)
LOG6	1/8" - 7/8" (3mm - 22mm)	1/2" - 1 1/8" (13mm - 35mm)

Labels: RETAINING CABLE, FRAME KIT, FIXATION BRACKET TAB, Position 1, Position 2

B- INSERT AND TIGHTEN THE FRAME KIT IN THE CUT-OUT. MAKE SURE THE FIXATION BRACKETS ARE OPEN FOR PROPER INSTALLATION.
C- FINISH THE ASSEMBLY BY PLASTERING, SANDING AND PAINTING.

