


**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.


## NEW CONCRETE INSTALLATION PREPARATION (WITH FLANGE ACCESSORY S4663)

- A- PREPARE THE DESIRED DRAINING USING 8"-12" (20-30cm) OF GRAVEL UNDER THE FLANGE.
- B- INSTALL AN APPROPRIATE ELECTRICAL CONDUIT (**NOT INCLUDED**) THROUGH THE FLANGE.
- C- FEED CABLE THROUGH THE ELECTRICAL CONDUIT.
- D- POUR CONCRETE IN AND MAKE SURE THAT IT SITS 5mm UNDER THE TOP OF THE FLANGE.

A + B + C





D



## PRE-EXISTING SURFACE INSTALLATION PREPARATION

- A- MAKE HOLE IN CONCRETE SURFACE OR OTHER. USE ANCHORS IF NECESSARY (2X TYP. NOT INCLUDED)
- B- FASTEN MOUNTING BASE TO LEVELLED SURFACE USING (2X TYP.) SCREWS (NOT INCLUDED)


A + B



**FIXTURE INSTALLATION  
INTEGRAL DRIVER (120-277V)  
DIMMING 0-10V**

- A- UNFASTEN THE (4) SCREWS USING THE ALLEN KEY (**INCLUDED**).
- B- REMOVE THE BOLLARD BODY FROM THE BOLLARD BASE.
- C- LOWER THE BOLLARD BASE ON THE FLANGE'S THREADED ROD AND FASTEN IT WITH THE M6 NUTS (**INCLUDED**).
- D- MAKE THE NECESSARY WIRE CONNECTIONS (**SEE WIRING DIAGRAM**) USING WATERTIGHT CONNECTORS (**NOT INCLUDED**)

**A + B**



**C + D**

