


IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

### **INSTALLING PROJECTOR ON A THREE CIRCUIT PULSE TRACK (120V)**


FOR USE WITH GLOBAL PULSE® (120V) THREE CIRCUIT TRACK SYSTEM ONLY (0266, 0267, 0268).


- A- INSERT THE PROJECTOR TRACK ADAPTOR WITH THE POLARITY GROOVE TOWARDS THE POLARITY RIDGE ON THE TRACK AND PUSH INTO THE TRACK UNTIL IT SNAPS INTO PLACE.
- B- PUSH THE MECHANICAL FIXING LEVER TO THE RIGHT TO LOCK THE PROJECTOR INTO THE TRACK.
- C- SELECT THE DESIRED CIRCUIT WITH THE CIRCUIT SELECTOR SWITCH AND PUSH LEFT THE 0-10V SWITCH.




### REMOVING PROJECTOR FROM A THREE CIRCUIT PULSE TRACK

- A- SELECT THE POSITION (OFF) ON THE CIRCUIT SELECTOR SWITCH AND PUSH THE 0-10V SWITCH TO THE RIGHT.
- B- TURN THE MECHANICAL FIXING LEVER AS SHOWN TO UNLOCK THE PROJECTOR FROM THE TRACK.
- C- PULL FIRST FROM THE FIXING LEVER END TO REMOVE THE PROJECTOR FROM THE TRACK.







INS-527D

Last update: November 26, 2021


DM - R



# **PAN ANGLE POSITION**

A- SET TO THE DESIRED PAN POSITION (MAXIMUM OF 330° AXIAL ROTATION).


Δ




В

# **TILT ANGLE POSITION**

A- LOOSEN THE TILT ADJUSTMENT LOCKING SCREW USING A SLOTTED SCREWDRIVER.
B- SET TO THE DESIRED TILT POSITION (MAXIMUM OF 90° AXIAL ROTATION) AND FASTEN THE SCREW (DO NOT OVERTIGHTEN).



TO CHANGE THE TILT ANGLE WILL CAUSE INTERNAL DAMAGE TO THE PROJECTOR.




SISTEMALUX

Last update: November 26, 2021




### **REPLACING OPTIC**

- A- UNSCREW THE OPTIC HOLDER TO ACCESS THE REFLECTOR.
- B- REPLACE THE REFLECTOR AND RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.



# **REPLACING OPTIC**

- A- UNSCREW THE OPTIC HOLDER
- B- PLACE ACCESSORY BETWEEN THE OPTIC HOLDER AND THE ACCESSORY HOLDER
- C- RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.



**SISTEMALUX**