

**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.  
 THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

**INSTALLATION REMOTE MODEL ON JUNCTION BOX FOR ALL MODELS**


- A- UNFASTEN THE COUPLER FROM THE CANOPY.
- B- SCREW THE CROSSBAR TO THE JUNCTION BOX, USING (2) 8-32 SCREWS (NOT INCLUDED).
- C- MAKE ALL THE NECESSARY CONNECTIONS (SEE WIRING DIAGRAM) USING TWIST CONNECTORS (NOT INCLUDED).
- D- LIFT THE CANOPY UP TO THE CROSSBAR AND SCREW TIGHT THE COUPLER WITH THE ZINC PLATED NIPPLE.

A + B + C + D

**WIRING DIAGRAM**

REMOTE MODEL


LED +	RED
LED -	BLACK



**INSTALLATION TRIAC / ELV (LTE) OR DIMMING 0-10V (D10) ON JUNCTION BOX FOR SMALL MODEL**


- A- UNFASTEN THE COUPLER FROM THE CANOPY.
- B- SCREW THE CROSSBAR TO THE JUNCTION BOX, USING (2) 8-32 SCREWS (NOT INCLUDED).
- C- MAKE ALL THE NECESSARY CONNECTIONS (SEE WIRING DIAGRAM) USING TWIST CONNECTORS (NOT INCLUDED).
- D- LIFT THE CANOPY UP TO THE CROSSBAR AND SCREW TIGHT THE COUPLER WITH THE ZINC PLATED NIPPLE.

A + B + C + D



**WIRING DIAGRAM**


DIMMING 120V ONLY  
TRIAC / ELV (LTE)



FIXTURE CABLES

**WIRING DIAGRAM**

DIMMING 120-277V  
0-10V (D10)




FIXTURE CABLES

**INSTALLATION TRIAC / ELV (LTE) OR DIMMING 0-10V (D10) ON JUNCTION BOX FOR MEDIUM AND LARGE MODEL**


- A- UNFASTEN THE COUPLER FROM THE CANOPY.
- B- SCREW THE CROSSBAR TO THE JUNCTION BOX, USING (2) 8-32 SCREWS (NOT INCLUDED).
- C- MAKE ALL THE NECESSARY CONNECTIONS (SEE WIRING DIAGRAM) USING TWIST CONNECTORS (NOT INCLUDED).
- D- LIFT THE CANOPY UP TO THE CROSSBAR AND SCREW TIGHT THE COUPLER WITH THE ZINC PLATED NIPPLE.

A + B + C + D



**WIRING DIAGRAM**


DIMMING 120V ONLY  
TRIAC / ELV (LTE)



FIXTURE CABLES

**WIRING DIAGRAM**

DIMMING 120-277V  
0-10V (D10)




FIXTURE CABLES

**INSTALLATION WITH INTEGRAL DRIVER  
DIMMING 0-10V (D01) / LUTRON HI LUME® 1% ECOSYSTEM™ (D2B) / LUTRON HI LUME® 1% 2-WIRE  
(120V FORWARD PHASE ONLY) (D3) FOR ALL MODEL ON JUNCTION BOX**


- A- UNFASTEN THE CANOPY PHILLIPS SCREWS, AND REMOVE THE CROSSBAR FROM THE CANOPY.  
KEEP THE SCREWS IN SAFE PLACE.
- B- SCREW THE CROSSBAR TO THE JUNCTION BOX, USING (2) 8-32 SCREWS (**NOT INCLUDED**).
- C- MAKE ALL THE NECESSARY CONNECTIONS (**SEE WIRING DIAGRAM**) USING TWIST CONNECTORS (**NOT INCLUDED**).
- D- LIFT THE CANOPY UP TO THE CROSSBAR AND FASTEN WITH THE KEPT PHILLIPS SCREWS.

A + B + C + D



**WIRING DIAGRAM**


DIMMING 120V ONLY  
TRIAC/ELV (LTE) or TRIAC (D3)



FIXTURE CABLES

**WIRING DIAGRAM**

DIMMING 120-277V  
0-10V (D01) or BUS SUPPLY (D2B)




FIXTURE CABLES

**CABLE LENGTH ADJUSTMENT FLAT CANOPY ONLY (WITHOUT DRIVER ON CROSSBAR)**

- A- UNFASTEN THE P-CLIP SCREW ON THE TOP AT THE CROSSBAR.
- B- PULL THE POWER CABLE AND ADJUST TO DESIRED LENGTH. FASTEN THE P-CLIP SCREW.
- C- CUT THE EXCESS CABLE AND MAKE ALL NECESSARY CONNECTIONS (FOLLOW POLARITY).

**A + B + C**



**⚠ DISCONNECT THE MAIN LINE BEFORE ADJUST THE CABLE LENGTH.**

**CABLE LENGTH ADJUSTEMENT**

- A- UNFASTEN THE PHILLIPS SCREWS ON THE CAP.
- B- DISCONNECT THE QUICKS CONNECTORS AND UNFASTEN THE SET SCREW USING ALLEN KEY (NOT INCLUDED).
- C- ADJUST THE POWER CABLE TO DESIRED LENGTH.
- D- FASTEN THE SET SCREW TIGHT TO LOCK POSITION AND MAKE ALL NECESSARY CONNECTIONS (FOLLOW POLARITY).
- E- LOWER CAP AND FASTEN THE PHILLIPS SCREW.

