

**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.


## INSTALLING PROJECTOR WITH CANOPY (120-277V)

FOR USE WITH STANDARD 4" JUNCTION BOX (120-277V)

A - MAKE WIRE CONNECTIONS (SEE WIRING DIAGRAM BELOW). \*FOR OPTIONAL DIMMING 0-10V: WIRES MUST BE RUN THROUGH A SEPARATE KNOCK OUT HOLE WHEN CONNECTING DIMMING CONTROLLER.

B - SCREW CANOPY ON THE JUNCTION BOX USING THE (2) PHILLIPS HEAD SCREWS (INCLUDED).


A + B



## PAN ANGLE POSITION (1770C)

A - ADJUST THE DESIRED PAN POSITION. (MAXIMUM OF 330° AXIAL ROTATION).


A



## TILT ANGLE POSITION (1770C)

A - ROTATE THE FIXTURE TO DESIRED TILT POSITION (MAXIMUM OF 90° AXIAL ROTATION).

A




## REPLACING OPTIC

A - UNSCREW THE OPTIC HOLDER TO ACCESS THE REFLECTOR.

B - REPLACE THE REFLECTOR AND RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

A + B



## ACCESSORIES

A - UNSCREW THE OPTIC HOLDER

B - PLACE ACCESSORY BETWEEN THE OPTIC HOLDER AND THE ACCESSORY HOLDER

C - RE-INSTALL THE OPTIC HOLDER BACK IN PLACE.

A + B + C

