





**IMPORTANT** - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

**WOOD SLAT GRID CEILING INSTALATION (W)  
INTEGRAL DRIVER (120V / 120-277V)  
DIMMING 0-10V (D10) - DALI (EDA, SDA) - TRIAC / ELV (LTE)**

- A- REMOVE THE (4) PHILLIPS SCREWS IN ORDER TO OPEN HOUSING.
- B- INSTAL THE BX CABLE (**NOT INCLUDED**) USING BX CONNECTOR (**INCLUDED**).
- C- CLOSE THE HOUSING BY SCREWING THE (4) PHILLIPS SCREWS PREVIOUSLY REMOVED (A). LEAVE AT LEAST 6" (152mm) OF FEEDER CABLE ACCESSIBLE FROM UNDER THE CEILING.
- D- SLIDE THE (4) HANGER BARS IN HOUSING SLOTS AVAILABLE AND CONNECT THEM TOGETHER.
- E- ADJUST THE DISTANCE FROM THE HANGER BARS TO STRUCTURE BY SLIDING THEM INTO EACHOTHER (1), AND PLACE THE HANGAR BAR ONTO THE T-BAR USING THE APPROPRIATE SLOT (2).



**FIXTURE INSTALLATION**

- A- CLIP THE AIRCRFAT SECURITY FROM THE HOUSIN TO THE LASER BLAED FIXTURE.
- B- CONNECT THE DRIVER TO THE FEEDER CABLE (**FOLLOWING WIRING DIAGRAM**) WITH QUICK CONNECTORS (**INCLUDED**).  
**DIMMING WIRES WILL BE SUPPLIED WITH QUICK CONNECTORS.**
- C- PLACE PHILLIPS SCREWDRIVER IN ALLOCATED POSITION AND FASTEN THE POWER SUPPLY TO THE TOP OF THE INSULATION BOX, TIGHTEN POWER SUPPLY IN THE ALIGNMENT BRACKET.
- D- ALIGN THE LASER BALDE FIXTURE WITH THE HOLES LOACTED ON THE HOUSING AND SECURE IT IN PLACE USING THE INCLUDED PHILIPS SREWS.

A + B + C + D

